



BY **daintree** INDUSTRIES 

## CLASSIC SERIES INSTALLATION GUIDE - wall mount

### Supplied Hardware

Stainless Steel M2.5 bolt (1 per fin)

#6 Specialty screw (1 per hole in back of post)

**NOTE:** Wall anchors may be required if fastening to masonry.

### Tools Required

Aluminum blade + chop saw

Level or Laser

Drill + drill bit

#1 Robinson bit

1mm Allen Key

**1** - Remove post from packaging. Be sure to recycle!

**2** - Determine location on wall via Interior Designers Drawings or Liquid Systems Shop Drawings.

**NOTE:** Ensure adequate bottle space either side to existing and future objects to ensure intended bottle storage and display is achievable.

**NOTE:** If light shelves are integral to the purchased display, pre-wiring and locations would have been pre-determined in order to supply required power and switching functions.

**3** - Mark edge or centerline of post on, or close to floor.

**4** - By use of a level or laser, mark the edge or centerline of post on or close to the ceiling to ensure a plumb installation.

**5** - Measure overall floor to ceiling height at marked location and cut post to length using an aluminum blade and chop saw.

**NOTE:** Posts are marked with "top" and "bottom" labels. Be sure to trim the correct end as key holes are specific to this vertical orientation.

**NOTE:** If multiple posts are being installed, ensure level and alignment of bottle display. First post (or multiple posts) may need to be trimmed top and bottom to gain a level installation over multiple posts.


**6** - Lean post against wall and align with top and bottom edge markings laid out from step #4-#5.

**7** - Mark holes with pencil per hole in back of post.


**8** - Set post aside and pre-drill into wall surface and blocking behind with a 1/16" (1.5mm) drill bit, ensuring alignment with markings from previous step.

**NOTE:** If light shelves are part of the post, install light shelf before installing post. Make required electrical connections with wires supplied in pre-allocated locations.


**diagram #1** :: cut to length



**diagram #2** :: mark holes



**diagram #3** :: pre-drill






BY **daintree** INDUSTRIES


## CLASSIC SERIES INSTALLATION GUIDE - wall mount

- 9** - Secure post with #6 specialty screws (supplied).
- 10** - Repeat steps #2-#9 for multiple post installations ensuring adequate space between posts (recommended minimum = 14" between centrelines of posts).
- 11** - Open packaging with fin supports. Confirm supply type, colour and quantity matches order.
- 12** - Remove hardware from packaging.
- NOTE:** Supplied hardware = 1 x M2.5 Stainless Steel bolt per fin.
- 13** - Fin supports are packaged in a way to protect quality and finish of the product during transportation. Remove exposed fins as installing, then remove protective paper to reveal second layer of fins.
- 14** - Start installing fins by removing exposed fins from packaging. Installing each fin individually so the pre-drilled hole in fin aligns with the threaded hole in post.
- NOTE:** Start installation from lowest fin location and work up. This allows any gentle tapping from above if required on snug fitting fins.
- NOTE:** For cantilevered display the top and bottom fins are different to the rest. These will be part of the exposed fins in packaging. Ensure these are installed in top or bottom locations.
- 15** - Once key of fin is installed and fin is nested on post, secure fin by installing M2.5 bolt and finger tighten with 1mm allen key.
- NOTE:** Use allen key only in orientation shown as to not create excessive torque. Finger-tight is all that is required to make a snug fit. Use extreme caution not to overtighten and strip thread in post.
- 16** - Repeat until all fins are installed.
- 17** - Sit back and enjoy!

**diagram #4** :: fasten post



**diagram #5** :: install fins



**diagram #6** :: keep on going!

